




## Quick Start Guide



## SAFETY INSTRUCTION

- Improper or incorrect use of batteries may cause corrosion or battery leakage, which could cause personal injury or damage to property.
- Install the batteries correctly by following the polarity (+ and -) indications in the battery compartment.
- Use only the types of the batteries which are indicated in this manual.
- Do not dispose the used batteries as domestic waste. Dispose them in accordance with local regulations
- Not suitable for children under 36 months . Small parts.
- Warning. Not suitable for children under 18 months. Long Cord. Strangulation hazard.

## 1


## OVERVIEW

### IMPORTANT NOTE

It is very important that you read the User Guide carefully as it contains detailed information.

Please refer to the complete user manual which is available online at:

[www.wiltec.hk](http://www.wiltec.hk)



### Pack Contents

- 1 JET unit
- 1 CR2032 battery
- 1 Quick Start Guide
- 1 Adjustable Strap

# JET

For more Information:  
[www.wiltec.hk](http://www.wiltec.hk)

Model No.: WT-0070

## 2

## APP

Install the "Tracker" APP on your Android Device, which can be found by scanning the QR code below.



NOTE: the "Tracker" APP support only Android Device with Android 4.4.2 or above.



All rights reserved.

Wiltec HK Company Limited  
Model : WT-0070

Use only battery type listed in user manual

Made in China

## 3 SETTING UP JET

The JET operates with a CR2032 battery. Open the battery door at the back of the JET, insert a CR2032 battery, observing the correct polarity, then close the battery door.

Make sure the battery door is firmly shut to prevent children from swallowing the battery.

The indicator light LED will be blinking and the JET is ready to connect the smartphone. JET will keep in the waiting for connection state for 4mins. Afterwards, it will go to sleep mode and the indicator light will be off.

You can press the "Action" Button on the JET once to wake up the JET to wait for 4 mins again

### Smartphone

Turn on Bluetooth on your smartphone and open the APP.

The APP will connect to the JET automatically, if the JET is on and within the working range.

After successfully connected, the Indicator light LED on the JET will be off.

(If the Bluetooth function of smartphone is not activated, the APP will request to enable the Bluetooth.

Please select "YES" to activate the Bluetooth on smartphone.)


## 5 USING YOUR JET

### Devices

At the bottom of the APP Main Menu, the available JET devices are listed and represented by an round icon with, its name is displayed under.

At the upper-right corner of the icon, there is a small circle whose color is indicating the connection status of the JET:

- Red status: means disconnected
- Green status: means connected.

TIPS: if you find your JET in Red status, you can press the refresh icon  to re-build Bluetooth connection again.

### Alarms

There are 3 distance alarm levels plus 1 Link Loss alarm settings on the ring which is in the upper part of the APP's Main Menu.

The three distance alarm levels are "Near", "Normal" and "Far".



You can slide the red button along the ring to change alarm setting.

Also, you can tap on the top, bottom, left or right part of the ring to change the setting, the distance setting are as follow .

Level	Near	Normal	Far
Distance	6 - 10 m	15 - 20 m	30 - 40 m

-On the JET, the indicator light LED will be blinking and the buzzer will be active. You can press the "Action" button to stop the alarm.

-On the smartphone, it will display an "Out of Range" warning message with sound alert and also, it will receive a status bar notification You can tap on the message to stop the alarm.



Similarly for Link Loss alarm, the alert will be triggered while the JET has lost Bluetooth connection with your smartphone.

### PAGER

You can trigger an immediate alarm on the JET by tapping on the "Pager" icon in the APP. The indicator light LED is blinking and the buzzer tone is active on the JET.

### SOUND

You can tap on the "Sound" icon to enable/disable the Sound alarm on the JET.



### Find Me

When the JET is connected to the smartphone, you can press the "Action" button of JET once to page the smartphone.

The APP will receive a notification on the status bar with alert sound and display "Find Me".

### Stop Alarm

You can press the "Action" Button once to stop the alarm once triggered by distance or link loss (the indicator light LED is blinking and buzzer is ringing.)

### UV Indicator

There is a UV sensor indicator below the "Action" button on the front of the JET which shows 4 levels of color change from light to intense.

The indicator will change color accordingly to the UV lights it is exposing to. You can compare the label color with the 4 levels to get a rough estimation on your current environment about UV exposure and take necessary precaution.

TIPS: The UV indicator will be expired over one-year use.

## TECHNICAL SPECIFICATION

### JET

Power Supply : One CR2032 3V Lithium Battery  
Transmission Frequency: 2400 - 2483.5MHz  
Transmission power: 4dBm max

### Battery

CR2032 3V Lithium Battery

### i

To access the user instruction online, use the reference model number written at the bottom of the Cover Page of this Quick Start Guide.

[www.wiltec.hk](http://www.wiltec.hk)

## NOTE

Declaration of Conformity can be found on :  
[www.wiltec.hk/DOC](http://www.wiltec.hk/DOC)